AMR 24 Schematics


Klark Teknik Building Walter Nash Road Kidderminster Worcestershire DY11 7HJ

Tel: +44 (0) 1562 741515 Fax: +44 (0) 1562 745371


Email: info@uk.telex.com
Website: www.ddaconsoles.com


AMR24 Schematics © Telex Communications (UK) Limited

In line with the company's policy of continual improvement, specifications and function maybe subject to change without notice. This Operator Manual was correct at the time of writing. E&OE.





1








EBO Circuit Diagram


















AMR24/DCM232 Master Modules Block Diagrams

ırlı.










AMR24 Input Module

AMR24 Output Module

AMR/DCM Talkback Master Module

AMR/DCM Oscillator Master Module

AMR/DCM Studio Master Module



AMR/DCM Control Room Master Module